


2012 - Mazda6 - Engine

FOREWORD [MZI 3.7 V6]

- When the customer reports a vehicle malfunction, check the malfunction indicator lamp (MIL) indication and diagnostic trouble code (DTC), then diagnose the malfunction according to following flowchart.
 - If the DTC exists, diagnose the applicable DTC inspection. (See [DTC TABLE \[MZI 3.7 V6\]](#).)
 - If the DTC does not exist and the MIL does not illuminate, diagnose the applicable symptom troubleshooting.




*: MIL, Generator Warning Light, Security Light

2012 - Mazda6 - Engine

FOREWORD [MZI 3.7 V6]

- When the customer reports a vehicle malfunction, check the malfunction indicator lamp (MIL) indication and diagnostic trouble code (DTC), then diagnose the malfunction according to following flowchart.
 - If the DTC exists, diagnose the applicable DTC inspection. (See [DTC TABLE \[MZI 3.7 V6\]](#).)
 - If the DTC does not exist and the MIL does not illuminate, diagnose the applicable symptom troubleshooting.



*: MIL, Generator Warning Light, Security Light