

[< Previous](#) [Next >](#)

2012 - Mazda6 - Body and Accessories

AUTO LIGHT/ WIPER CONTROL MODULE REMOVAL/ INSTALLATION

NOTE:

- Auto wiper system are integrated with the auto light/wiper control module.
1. Disconnect the negative battery cable.
 2. Remove the dashboard under cover (driver-side). (See [DASHBOARD UNDER COVER REMOVAL/ INSTALLATION](#).)
 3. Remove the auto light/wiper control module. (See [AUTO LIGHT-OFF CONTROL MODULE REMOVAL/ INSTALLATION](#).)
 4. Install in the reverse order of removal.

[< Previous](#) [Next >](#)

[Back to Top](#)

© 2012 Mazda North American Operations, U.S.A.

[< Previous](#) [Next >](#)

2012 - Mazda6 - Body and Accessories

AUTO LIGHT/ WIPER CONTROL MODULE REMOVAL/ INSTALLATION

NOTE:

- Auto wiper system are integrated with the auto light/wiper control module.
1. Disconnect the negative battery cable.
 2. Remove the dashboard under cover (driver-side). (See [DASHBOARD UNDER COVER REMOVAL/ INSTALLATION](#).)
 3. Remove the auto light/wiper control module. (See [AUTO LIGHT-OFF CONTROL MODULE REMOVAL/ INSTALLATION](#).)
 4. Install in the reverse order of removal.

[< Previous](#) [Next >](#)

[Back to Top](#)

© 2012 Mazda North American Operations, U.S.A.