


2012 - Mazda6 - Body and Accessories


REAR DOOR SPEAKER REMOVAL/ INSTALLATION

1. Disconnect the negative battery cable.
2. Remove the rear door trim. (See [REAR DOOR TRIM REMOVAL/ INSTALLATION.](#))
3. Remove in the order indicated in the table.

With Bose®



Without Bose®




1	Screw
2	Connector
3	Rear door speaker (See Rear Door Speaker Removal Note .)

4. Install in the reverse order of removal.


Rear Door Speaker Removal Note

1. Remove the rear door speaker in the direction of the arrow shown in the figure.

With Bose®



Without Bose®




2012 - Mazda6 - Body and Accessories


REAR DOOR SPEAKER REMOVAL/ INSTALLATION

1. Disconnect the negative battery cable.
2. Remove the rear door trim. (See [REAR DOOR TRIM REMOVAL/ INSTALLATION.](#))
3. Remove in the order indicated in the table.

With Bose®



Without Bose®




1	Screw
2	Connector
3	Rear door speaker (See Rear Door Speaker Removal Note .)

4. Install in the reverse order of removal.

Rear Door Speaker Removal Note

1. Remove the rear door speaker in the direction of the arrow shown in the figure.

With Bose®



Without Bose®

