


2012 - Mazda6 - Body and Accessories

AUDIO UNIT REMOVAL/ INSTALLATION

1. Disconnect the negative battery cable.
2. Remove the following parts:
 - a. Upper panel (See [UPPER PANEL REMOVAL/ INSTALLATION](#).)
 - b. Decoration panel (See [DECORATION PANEL REMOVAL/ INSTALLATION](#).)
 - c. Shift knob (MTX) (See [MANUAL TRANSAXLE SHIFT MECHANISM REMOVAL/ INSTALLATION](#).)
 - d. Shift panel (See [SHIFT PANEL REMOVAL/ INSTALLATION](#).)
 - e. Center panel lower (See [CENTER PANEL LOWER REMOVAL/ INSTALLATION](#).)
 - f. Center panel upper (See [CENTER PANEL UPPER REMOVAL/ INSTALLATION](#).)
 - g. Climate control unit (See [CLIMATE CONTROL UNIT REMOVAL/ INSTALLATION \[FULL-AUTO AIR CONDITIONER\]](#).) (See [CLIMATE CONTROL UNIT REMOVAL/ INSTALLATION \[MANUAL AIR CONDITIONER\]](#).)
3. Remove in the order indicated in the table.
4. Install in the reverse order of removal.

CAUTION:


- When installing the audio unit, make sure that the wiring harness and antenna feeder are not caught between the unit and dashboard. If the wiring harness or the antenna feeder is caught between the unit and dashboard, it may cause malfunctions.



1 Bolt
2 Screw
3 Audio unit (See Audio Unit Removal Note.)
4 Connector
5 Antenna feeder

Audio Unit Removal Note

1. Pull the audio unit outward, detach tab, clip from the dashboard, and then remove the audio unit.



[< Previous](#) [Next >](#)

© 2012 Mazda North American Operations, U.S.A.

[Back to Top](#)


2012 - Mazda6 - Body and Accessories

AUDIO UNIT REMOVAL/ INSTALLATION

1. Disconnect the negative battery cable.
2. Remove the following parts:
 - a. Upper panel (See [UPPER PANEL REMOVAL/ INSTALLATION.](#))
 - b. Decoration panel (See [DECORATION PANEL REMOVAL/ INSTALLATION.](#))
 - c. Shift knob (MTX) (See [MANUAL TRANSAXLE SHIFT MECHANISM REMOVAL/ INSTALLATION.](#))
 - d. Shift panel (See [SHIFT PANEL REMOVAL/ INSTALLATION.](#))
 - e. Center panel lower (See [CENTER PANEL LOWER REMOVAL/ INSTALLATION.](#))
 - f. Center panel upper (See [CENTER PANEL UPPER REMOVAL/ INSTALLATION.](#))
 - g. Climate control unit (See [CLIMATE CONTROL UNIT REMOVAL/ INSTALLATION \[FULL-AUTO AIR CONDITIONER\].](#)) (See [CLIMATE CONTROL UNIT REMOVAL/ INSTALLATION \[MANUAL AIR CONDITIONER\].](#))
3. Remove in the order indicated in the table.
4. Install in the reverse order of removal.

CAUTION:


- When installing the audio unit, make sure that the wiring harness and antenna feeder are not caught between the unit and dashboard. If the wiring harness or the antenna feeder is caught between the unit and dashboard, it may cause malfunctions.



1 Bolt
2 Screw
3 Audio unit (See Audio Unit Removal Note.)
4 Connector
5 Antenna feeder

Audio Unit Removal Note

1. Pull the audio unit outward, detach tab, clip from the dashboard, and then remove the audio unit.



[< Previous](#) [Next >](#)

© 2012 Mazda North American Operations, U.S.A.

[Back to Top](#)