


2012 - Mazda6 - Body and Accessories

Bluetooth UNIT REMOVAL/ INSTALLATION

1. Disconnect the negative battery cable.
2. Remove the following parts:
 - a. Front scuff plate (RH) (See [FRONT SCUFF PLATE REMOVAL/ INSTALLATION.](#))
 - b. Front side trim (RH) (See [FRONT SIDE TRIM REMOVAL/ INSTALLATION.](#))
 - c. Glove compartment (See [GLOVE COMPARTMENT REMOVAL/ INSTALLATION.](#))
 - d. Audio amplifier (With Bose®) (See [AUDIO AMPLIFIER REMOVAL/ INSTALLATION.](#))
3. Remove in the order indicated in the table.



1	Nut
---	-----

2	Connector
3	Bluetooth unit

4. Install in the reverse order of removal.

[< Previous](#) [Next >](#)


[Back to Top](#)

© 2012 Mazda North American Operations, U.S.A.

2012 - Mazda6 - Body and Accessories

Bluetooth UNIT REMOVAL/ INSTALLATION

1. Disconnect the negative battery cable.
2. Remove the following parts:
 - a. Front scuff plate (RH) (See [FRONT SCUFF PLATE REMOVAL/ INSTALLATION.](#))
 - b. Front side trim (RH) (See [FRONT SIDE TRIM REMOVAL/ INSTALLATION.](#))
 - c. Glove compartment (See [GLOVE COMPARTMENT REMOVAL/ INSTALLATION.](#))
 - d. Audio amplifier (With Bose®) (See [AUDIO AMPLIFIER REMOVAL/ INSTALLATION.](#))
3. Remove in the order indicated in the table.



1	Nut
---	-----

2	Connector
3	Bluetooth unit

4. Install in the reverse order of removal.

[< Previous](#) [Next >](#)

[Back to Top](#)

© 2012 Mazda North American Operations, U.S.A.