


2012 - Mazda6 - Body and Accessories

INSTRUMENT CLUSTER DI SASSEMBLY/ ASSEMBLY

CAUTION:

- Do not drop the instrument cluster or damage the printed board. This will lead to a system malfunction.
1. Perform the instrument cluster configuration when replacing it. (See [INSTRUMENT CLUSTER CONFIGURATION](#).)
 2. Disconnect the negative battery cable.
 3. Remove the meter hood. (See [METER HOOD REMOVAL/ INSTALLATION](#).)
 4. Remove the instrument cluster. (See [INSTRUMENT CLUSTER REMOVAL/ INSTALLATION](#).)
 5. Disassemble in the order indicated in the table.



1	Case
2	Ring
3	Lens
4	Cover
5	Instrument cluster unit

6. Assemble in the reverse order of disassembly.

[< Previous](#) [Next >](#)

[Back to Top](#)


© 2012 Mazda North American Operations, U.S.A.

2012 - Mazda6 - Body and Accessories

INSTRUMENT CLUSTER DI SASSEMBLY/ ASSEMBLY

CAUTION:

- Do not drop the instrument cluster or damage the printed board. This will lead to a system malfunction.
1. Perform the instrument cluster configuration when replacing it. (See **INSTRUMENT CLUSTER CONFIGURATION**.)
 2. Disconnect the negative battery cable.
 3. Remove the meter hood. (See **METER HOOD REMOVAL/ INSTALLATION**.)
 4. Remove the instrument cluster. (See **INSTRUMENT CLUSTER REMOVAL/ INSTALLATION**.)
 5. Disassemble in the order indicated in the table.



1	Case
2	Ring
3	Lens
4	Cover
5	Instrument cluster unit

6. Assemble in the reverse order of disassembly.

[< Previous](#) [Next >](#)

[Back to Top](#)

© 2012 Mazda North American Operations, U.S.A.