

[< Previous](#) [Next >](#)

2012 - Mazda6 - Body and Accessories

BLIND SPOT MONITORING (BSM) INDICATOR LIGHT REMOVAL/ INSTALLATION

- The BSM indicator lights are integrated into the outer mirror glass.
- When removing/installing the BSM indicator lights, refer to the procedure, "OUTER MIRROR GLASS REMOVAL/INSTALLATION". (See [OUTER MIRROR GLASS REMOVAL.](#)) (See [OUTER MIRROR GLASS INSTALLATION.](#))

[< Previous](#) [Next >](#)

[Back to Top](#)

© 2012 Mazda North American Operations, U.S.A.

[< Previous](#) [Next >](#)

2012 - Mazda6 - Body and Accessories

BLIND SPOT MONITORING (BSM) INDICATOR LIGHT REMOVAL/ INSTALLATION

- The BSM indicator lights are integrated into the outer mirror glass.
- When removing/installing the BSM indicator lights, refer to the procedure, "OUTER MIRROR GLASS REMOVAL/INSTALLATION". (See [OUTER MIRROR GLASS REMOVAL.](#)) (See [OUTER MIRROR GLASS INSTALLATION.](#))

[< Previous](#) [Next >](#)

[Back to Top](#)

© 2012 Mazda North American Operations, U.S.A.