


[< Previous](#) [Next >](#)

2012 - Mazda6 - Body and Accessories

CONTROL SYSTEM LOCATION INDEX



1 BCM

(See [BODY CONTROL MODULE \(BCM\) REMOVAL/ INSTALLATION.](#))

(See [BODY CONTROL MODULE \(BCM\) INSPECTION.](#))

(See [BODY CONTROL MODULE \(BCM\) CONFIGURATION.](#))

(See [CONTROL SYSTEM PERSONALIZATION FEATURES SETTING PROCEDURE.](#))


[< Previous](#) [Next >](#)

[Back to Top](#)

[< Previous](#) [Next >](#)

2012 - Mazda6 - Body and Accessories

CONTROL SYSTEM LOCATION INDEX



1 BCM

(See [BODY CONTROL MODULE \(BCM\) REMOVAL/ INSTALLATION.](#))

(See [BODY CONTROL MODULE \(BCM\) INSPECTION.](#))

(See [BODY CONTROL MODULE \(BCM\) CONFIGURATION.](#))

(See [CONTROL SYSTEM PERSONALIZATION FEATURES SETTING PROCEDURE.](#))

[< Previous](#) [Next >](#)

[Back to Top](#)