


2012 - Mazda6 - Engine

AFTER REPAIR PROCEDURE [MZR 2.5]

1. Connect the M-MDS (IDS) to the DLC-2.




2. After the vehicle is identified, select the following items from the initialization screen of the IDS.
 - a. Select "Self Test".
 - b. Select "Modules".
 - c. Select "PCM".
 - d. Select "Retrieve CMDTCs".
3. Verify the DTC according to the directions on the IDS screen.
4. Press the clear button on the DTC screen to clear the DTC.
5. Verify that no DTCs are displayed.

2012 - Mazda6 - Engine

AFTER REPAIR PROCEDURE [MZR 2.5]

1. Connect the M-MDS (IDS) to the DLC-2.



2. After the vehicle is identified, select the following items from the initialization screen of the IDS.
 - a. Select "Self Test".
 - b. Select "Modules".
 - c. Select "PCM".
 - d. Select "Retrieve CMDTCs".
3. Verify the DTC according to the directions on the IDS screen.
4. Press the clear button on the DTC screen to clear the DTC.
5. Verify that no DTCs are displayed.