



2012 - Mazda6 - Engine

ENGINE LOCATION INDEX [MZI 3.7 V6]

1	Engine (See COMPRESSION INSPECTION [MZI 3.7 V6] .) (See ENGINE REMOVAL/ INSTALLATION [MZI 3.7 V6] .) (See ENGINE DI SASSEMBLY/ ASSEMBLY [MZI 3.7 V6] .) (See ENGINE TUNE-UP [MZI 3.7 V6] .)
2	Engine cover (See ENGINE COVER REMOVAL/ INSTALLATION [MZI 3.7 V6] .)
3	Generator and A/C drive belt (See DRIVE BELT INSPECTION [MZI 3.7 V6] .) (See DRIVE BELT REMOVAL/ INSTALLATION [MZI 3.7 V6] .)
4	Power steering oil pump drive belt (See DRIVE BELT INSPECTION [MZI 3.7 V6] .) (See DRIVE BELT REMOVAL/ INSTALLATION [MZI 3.7 V6] .)
5	Drive belt auto tensioner (See DRIVE BELT AUTO TENSIONER INSPECTION [MZI 3.7 V6] .)
6	Tappet (See VALVE CLEARANCE INSPECTION/ ADJUSTMENT [MZI 3.7 V6] .)
7	Variable valve timing actuator (See VARIABLE VALVE TIMING ACTUATOR REMOVAL/ INSTALLATION [MZI 3.7 V6] .)
8	OCV (See OIL CONTROL VALVE (OCV) INSPECTION [MZI 3.7 V6] .) (See OIL CONTROL VALVE (OCV) REMOVAL/ INSTALLATION [MZI 3.7 V6] .)
9	Timing chain (See TIMING CHAIN REMOVAL/ INSTALLATION [MZI 3.7 V6] .)
10	Cylinder head gasket (See CYLINDER HEAD GASKET REPLACEMENT [MZI 3.7 V6] .)
11	Front oil seal (See FRONT OIL SEAL REPLACEMENT [MZI 3.7 V6] .)
12	Rear oil seal (See REAR OIL SEAL REPLACEMENT [MZI 3.7 V6] .)

2012 - Mazda6 - Engine

ENGINE LOCATION INDEX [MZI 3.7 V6]



1	Engine (See COMPRESSION INSPECTION [MZI 3.7 V6] .) (See ENGINE REMOVAL/ INSTALLATION [MZI 3.7 V6] .) (See ENGINE DI SASSEMBLY/ ASSEMBLY [MZI 3.7 V6] .) (See ENGINE TUNE-UP [MZI 3.7 V6] .)
2	Engine cover (See ENGINE COVER REMOVAL/ INSTALLATION [MZI 3.7 V6] .)
3	Generator and A/C drive belt (See DRIVE BELT INSPECTION [MZI 3.7 V6] .) (See DRIVE BELT REMOVAL/ INSTALLATION [MZI 3.7 V6] .)
4	Power steering oil pump drive belt (See DRIVE BELT INSPECTION [MZI 3.7 V6] .) (See DRIVE BELT REMOVAL/ INSTALLATION [MZI 3.7 V6] .)
5	Drive belt auto tensioner (See DRIVE BELT AUTO TENSIONER INSPECTION [MZI 3.7 V6] .)
6	Tappet (See VALVE CLEARANCE INSPECTION/ ADJUSTMENT [MZI 3.7 V6] .)
7	Variable valve timing actuator (See VARIABLE VALVE TIMING ACTUATOR REMOVAL/ INSTALLATION [MZI 3.7 V6] .)
8	OCV (See OIL CONTROL VALVE (OCV) INSPECTION [MZI 3.7 V6] .) (See OIL CONTROL VALVE (OCV) REMOVAL/ INSTALLATION [MZI 3.7 V6] .)
9	Timing chain (See TIMING CHAIN REMOVAL/ INSTALLATION [MZI 3.7 V6] .)
10	Cylinder head gasket (See CYLINDER HEAD GASKET REPLACEMENT [MZI 3.7 V6] .)
11	Front oil seal (See FRONT OIL SEAL REPLACEMENT [MZI 3.7 V6] .)
12	Rear oil seal (See REAR OIL SEAL REPLACEMENT [MZI 3.7 V6] .)