



2012 - Mazda6 - Engine

ENGINE COVER REMOVAL/ INSTALLATION [MZI 3.7 V6]

NOTE:

- Firmly pull the engine cover near the locations shown to disengage the retainers.

1. Remove the engine cover in the order indicated in the figure.





2. Install in the reverse order of removal.

2012 - Mazda6 - Engine

ENGINE COVER REMOVAL/ INSTALLATION [MZI 3.7 V6]

NOTE:

- Firmly pull the engine cover near the locations shown to disengage the retainers.
- Remove the engine cover in the order indicated in the figure.



- Install in the reverse order of removal.