


2012 - Mazda6 - Engine

PLUG HOLE PLATE REMOVAL/ INSTALLATION [MZR 2.5]

NOTE:

- Lift off and remove the plug hole plate from the installation areas as shown in the figure.

1. Remove the plug hole plate in the order indicated in the figure.



2. Install the plug hole plate in the reverse order of removal.


2012 - Mazda6 - Engine

PLUG HOLE PLATE REMOVAL/ INSTALLATION [MZR 2.5]

NOTE:

- Lift off and remove the plug hole plate from the installation areas as shown in the figure.

1. Remove the plug hole plate in the order indicated in the figure.



2. Install the plug hole plate in the reverse order of removal.