


2012 - Mazda6 - Engine

ACCELERATOR PEDAL REMOVAL/ INSTALLATION [MZR 2.5]

- 1. Disconnect the negative battery cable. (See BATTERY REMOVAL/ INSTALLATION [MZR 2.5].)
- 2. Remove in the order indicated in the table.




1	APP sensor connector
2	Accelerator pedal

- 3. Install in the reverse order of removal.

2012 - Mazda6 - Engine

ACCELERATOR PEDAL REMOVAL/ INSTALLATION [MZR 2.5]

- 1. Disconnect the negative battery cable. (See BATTERY REMOVAL/ INSTALLATION [MZR 2.5].)
- 2. Remove in the order indicated in the table.



1	APP sensor connector
2	Accelerator pedal

- 3. Install in the reverse order of removal.