


2012 - Mazda6 - Engine

EVAPORATIVE CHAMBER REMOVAL/ INSTALLATION [MZR 2.5]

1. Disconnect the negative battery cable. (See [BATTERY REMOVAL/ INSTALLATION \[MZR 2.5\]](#).)
2. Remove the evaporative chamber.




3. Install in the reverse order of removal.

2012 - Mazda6 - Engine

EVAPORATIVE CHAMBER REMOVAL/ INSTALLATION [MZR 2.5]

1. Disconnect the negative battery cable. (See [BATTERY REMOVAL/ INSTALLATION \[MZR 2.5\]](#).)
2. Remove the evaporative chamber.



3. Install in the reverse order of removal.