

[< Previous](#) [Next >](#)

2012 - Mazda6 - Transmission/ Transaxle

SHIFT SOLENOID E REMOVAL/ INSTALLATION [AY6A-EL]

NOTE:

- Shift solenoid E is not available (shipped) as a single part.
1. If the shift solenoid E is replaced, replace the control valve body. (See [CONTROL VALVE BODY REMOVAL/ INSTALLATION \[AY6A-EL\]](#) .)

[< Previous](#) [Next >](#)

[Back to Top](#)

© 2012 Mazda North American Operations, U.S.A.

[< Previous](#) [Next >](#)

2012 - Mazda6 - Transmission/ Transaxle

SHIFT SOLENOID E REMOVAL/ INSTALLATION [AY6A-EL]

NOTE:

- Shift solenoid E is not available (shipped) as a single part.
1. If the shift solenoid E is replaced, replace the control valve body. (See [CONTROL VALVE BODY REMOVAL/ INSTALLATION \[AY6A-EL\]](#) .)

[< Previous](#) [Next >](#)

[Back to Top](#)

© 2012 Mazda North American Operations, U.S.A.