




2012 - Mazda6 - HVAC

MAGNETIC CLUTCH INSPECTION [MANUAL AIR CONDITIONER]

1. Connect battery to terminal A of magnetic clutch and ground to A/C compressor body.






2. Verify that the magnetic clutch operates.
 - If there is any malfunction, replace the magnetic clutch.

2012 - Mazda6 - HVAC

MAGNETIC CLUTCH INSPECTION [MANUAL AIR CONDITIONER]

1. Connect battery to terminal A of magnetic clutch and ground to A/C compressor body.



2. Verify that the magnetic clutch operates.

- If there is any malfunction, replace the magnetic clutch.