


2012 - Mazda6 - HVAC

BLOWER MOTOR INSPECTION [MANUAL AIR CONDITIONER]

1. Connect battery positive voltage to terminal B and ground to terminal A of the blower motor and verify its operation.




- If not as specified, replace the blower motor.

2012 - Mazda6 - HVAC

BLOWER MOTOR INSPECTION [MANUAL AIR CONDITIONER]

1. Connect battery positive voltage to terminal B and ground to terminal A of the blower motor and verify its operation.



- If not as specified, replace the blower motor.