

2012 - Mazda6 - Body and Accessories

DTC B1342 [AUTO LIGHT/ WIPER CONTROL MODULE]

DESCRIPTION	Auto light/wiper control module is faulted
DETECTION CONDITION	Auto light/wiper control module microcomputer malfunction
POSSIBLE CAUSE	• Auto light/wiper control module malfunction

Diagnostic procedure

STEP	INSPECTION	ACTION
1	PERFORM DTC INSPECTION • Clear the DTC from the auto light/wiper control module memory using the M-MDS. (See CLEARING DTC [AUTO LIGHT/ WIPER CONTROL MODULE] .) • Perform the auto light/wiper control module DTC inspection using the M-MDS. (See DTC INSPECTION [AUTO LIGHT/ WIPER CONTROL MODULE] .) • Is the same DTC present?	Yes Replace the auto light/wiper control module, then go to the next step. (See AUTO LIGHT/ WIPER CONTROL MODULE REMOVAL/ INSTALLATION .)
		No Go to the next step.
2	VERIFY THAT NO OTHER DTCs ARE RECORDED • Are any DTCs present?	Yes Go to the applicable DTC inspection. (See DTC TABLE [AUTO LIGHT/ WIPER CONTROL MODULE] .)
		No DTC troubleshooting completed.

2012 - Mazda6 - Body and Accessories

DTC B1342 [AUTO LIGHT/ WIPER CONTROL MODULE]

DESCRIPTION	Auto light/wiper control module is faulted
DETECTION CONDITION	Auto light/wiper control module microcomputer malfunction
POSSIBLE CAUSE	• Auto light/wiper control module malfunction

Diagnostic procedure

STEP	INSPECTION	ACTION
1	PERFORM DTC INSPECTION • Clear the DTC from the auto light/wiper control module memory using the M-MDS. (See CLEARING DTC [AUTO LIGHT/ WIPER CONTROL MODULE] .) • Perform the auto light/wiper control module DTC inspection using the M-MDS. (See DTC INSPECTION [AUTO LIGHT/ WIPER CONTROL MODULE] .) • Is the same DTC present?	Yes Replace the auto light/wiper control module, then go to the next step. (See AUTO LIGHT/ WIPER CONTROL MODULE REMOVAL/ INSTALLATION .)
		No Go to the next step.
2	VERIFY THAT NO OTHER DTCs ARE RECORDED • Are any DTCs present?	Yes Go to the applicable DTC inspection. (See DTC TABLE [AUTO LIGHT/ WIPER CONTROL MODULE] .)
		No DTC troubleshooting completed.