

2012 - Mazda6 - Body and Accessories

DTC TABLE [AUTO LIGHT/ WIPER CONTROL MODULE]

DTC	Description	Detection condition	Reference
M-MDS display			
B1014	Rain sensor/auto light sensor error	Rain sensor/auto light sensor internal malfunction	(See DTC B1014 [AUTO LIGHT/ WIPER CONTROL MODULE] .)
B1317	Battery voltage high	Input voltage from the battery is excessively high	(See DTC B1317 [AUTO LIGHT/ WIPER CONTROL MODULE] .)
B1318	Battery voltage low	Input voltage from the battery is excessively low	(See DTC B1318 [AUTO LIGHT/ WIPER CONTROL MODULE] .)
B1342	Auto light/wiper control module is faulted	Auto light/wiper control module microcomputer malfunction	(See DTC B1342 [AUTO LIGHT/ WIPER CONTROL MODULE] .)
U2030	Rain sensor/auto light sensor communication fault	Communication error to rain sensor/auto light sensor	(See DTC U2030 [AUTO LIGHT/ WIPER CONTROL MODULE] .)

2012 - Mazda6 - Body and Accessories

DTC TABLE [AUTO LIGHT/ WIPER CONTROL MODULE]

DTC	Description	Detection condition	Reference
M-MDS display			
B1014	Rain sensor/auto light sensor error	Rain sensor/auto light sensor internal malfunction	(See DTC B1014 [AUTO LIGHT/ WIPER CONTROL MODULE] .)
B1317	Battery voltage high	Input voltage from the battery is excessively high	(See DTC B1317 [AUTO LIGHT/ WIPER CONTROL MODULE] .)
B1318	Battery voltage low	Input voltage from the battery is excessively low	(See DTC B1318 [AUTO LIGHT/ WIPER CONTROL MODULE] .)
B1342	Auto light/wiper control module is faulted	Auto light/wiper control module microcomputer malfunction	(See DTC B1342 [AUTO LIGHT/ WIPER CONTROL MODULE] .)
U2030	Rain sensor/auto light sensor communication fault	Communication error to rain sensor/auto light sensor	(See DTC U2030 [AUTO LIGHT/ WIPER CONTROL MODULE] .)