


2012 - Mazda6 - Body and Accessories

COIL ANTENNA REMOVAL/ INSTALLATION [ADVANCED KEYLESS ENTRY AND PUSH BUTTON START SYSTEM]

1. Disconnect the negative battery cable.
2. Remove the column cover. (See [COLUMN COVER REMOVAL/ INSTALLATION](#).)
3. Disconnect the coil antenna connector.




4. Remove the screw.
5. Detach the coil antenna hooks and remove the coil antenna from the steering lock.
6. Install in the reverse order of removal.

2012 - Mazda6 - Body and Accessories

COIL ANTENNA REMOVAL/ INSTALLATION [ADVANCED KEYLESS ENTRY AND PUSH BUTTON START SYSTEM]

1. Disconnect the negative battery cable.
2. Remove the column cover. (See [COLUMN COVER REMOVAL/ INSTALLATION](#).)
3. Disconnect the coil antenna connector.



4. Remove the screw.
5. Detach the coil antenna hooks and remove the coil antenna from the steering lock.
6. Install in the reverse order of removal.

