


2012 - Mazda6 - Body and Accessories

KEYLESS CONTROL MODULE CONFIGURATION [ADVANCED KEYLESS ENTRY AND PUSH BUTTON START SYSTEM]

1. Connect the M-MDS (IDS) to DLC-2.




2. After the vehicle is identified, select the following items from the initial screen of the IDS.
 - a. Select the "Module Programming".
 - b. Select "Programmable Module Installation".
 - c. Select "RKE".
3. Perform the configuration according to the directions on the screen.
4. Retrieve DTCs by the M-MDS, then verify that there is no DTC present.
 - If a DTC (s) is detected, perform the applicable DTC inspection. (See [DTC TABLE \[ADVANCED KEYLESS ENTRY AND PUSH BUTTON START SYSTEM\]](#) .)

2012 - Mazda6 - Body and Accessories

KEYLESS CONTROL MODULE CONFIGURATION [ADVANCED KEYLESS ENTRY AND PUSH BUTTON START SYSTEM]

1. Connect the M-MDS (IDS) to DLC-2.



2. After the vehicle is identified, select the following items from the initial screen of the IDS.
 - a. Select the "Module Programming".
 - b. Select "Programmable Module Installation".
 - c. Select "RKE".
3. Perform the configuration according to the directions on the screen.
4. Retrieve DTCs by the M-MDS, then verify that there is no DTC present.
 - If a DTC (s) is detected, perform the applicable DTC inspection. (See [DTC TABLE \[ADVANCED KEYLESS ENTRY AND PUSH BUTTON START SYSTEM\]](#) .)