



2012 - Mazda6 - Body and Accessories

KEYLESS BEEPER REMOVAL/ INSTALLATION [ADVANCED KEYLESS ENTRY AND PUSH BUTTON START SYSTEM]

1. Disconnect the negative battery cable.
2. Slightly bend back the front mudguard. (See [FRONT MUDGUARD REMOVAL/ INSTALLATION](#).)
3. Disconnect the connector.



4. Remove the bolt.
5. Press the keyless beeper tab aside using a tape-wrapped flathead screwdriver.



6. Remove the keyless beeper from the bracket.
7. Install in the reverse order of removal.


[< Previous](#) [Next >](#)

[Back to Top](#)


2012 - Mazda6 - Body and Accessories

KEYLESS BEEPER REMOVAL/ INSTALLATION [ADVANCED KEYLESS ENTRY AND PUSH BUTTON START SYSTEM]

1. Disconnect the negative battery cable.
2. Slightly bend back the front mudguard. (See [FRONT MUDGUARD REMOVAL/ INSTALLATION](#).)
3. Disconnect the connector.



4. Remove the bolt.
5. Press the keyless beeper tab aside using a tape-wrapped flathead screwdriver.



6. Remove the keyless beeper from the bracket.
7. Install in the reverse order of removal.

[< Previous](#) [Next >](#)

[Back to Top](#)