



2012 - Mazda6 - Body and Accessories

KEY REMINDER SWITCH INSPECTION [WITHOUT ADVANCED KEYLESS ENTRY AND PUSH BUTTON START SYSTEM]

- 1. Disconnect the negative battery cable.
- 2. Remove the column cover. (See [COLUMN COVER REMOVAL/ INSTALLATION.](#))
- 3. Disconnect the key reminder switch connector.



- 4. Verify that the continuity between the key reminder switch terminals is as indicated in the table.



- If not as indicated in the table, replace the key reminder switch.


○—○ : Continuity

Key position	Terminal	
	A	B
Key inserted	○ ——— ○	
Key removed		


2012 - Mazda6 - Body and Accessories

KEY REMINDER SWITCH INSPECTION [WITHOUT ADVANCED KEYLESS ENTRY AND PUSH BUTTON START SYSTEM]

- 1. Disconnect the negative battery cable.
- 2. Remove the column cover. (See [COLUMN COVER REMOVAL/ INSTALLATION.](#))
- 3. Disconnect the key reminder switch connector.



- 4. Verify that the continuity between the key reminder switch terminals is as indicated in the table.



- If not as indicated in the table, replace the key reminder switch.

○—○ : Continuity

Key position	Terminal	
	A	B
Key inserted	○ ——— ○	○ ——— ○
Key removed		

