


2012 - Mazda6 - Engine

LUBRICATION SYSTEM LOCATION INDEX [MZR 2.5]




1 Dipstick
(See [ENGINE OIL LEVEL INSPECTION \[MZR 2.5\]](#).)
[ENGINE OIL REPLACEMENT \[MZR 2.5\]](#)

	(See .)
2	Oil cooler (See OIL COOLER REMOVAL/ INSTALLATI ON [MZR 2.5] .)
3	Oil pressure switch (See OIL PRESSURE INSPECTI ON [MZR 2.5] .)
4	Oil filter (See OIL FILTER REPLACEMENT [MZR 2.5] .)
5	Oil pan (See OIL PAN REMOVAL/ INSTALLATI ON [MZR 2.5] .)
6	Oil strainer (See OIL PUMP REMOVAL/ INSTALLATI ON [MZR 2.5] .)
7	Oil pump component (See OIL PUMP REMOVAL/ INSTALLATI ON [MZR 2.5] .)

2012 - Mazda6 - Engine

LUBRICATION SYSTEM LOCATION INDEX [MZR 2.5]



1 Dipstick
(See [ENGINE OIL LEVEL INSPECTION \[MZR 2.5\]](#).)
[ENGINE OIL REPLACEMENT \[MZR 2.5\]](#)

	(See .)
2	Oil cooler (See OIL COOLER REMOVAL/ INSTALLATI ON [MZR 2.5] .)
3	Oil pressure switch (See OIL PRESSURE INSPECTI ON [MZR 2.5] .)
4	Oil filter (See OIL FILTER REPLACEMENT [MZR 2.5] .)
5	Oil pan (See OIL PAN REMOVAL/ INSTALLATI ON [MZR 2.5] .)
6	Oil strainer (See OIL PUMP REMOVAL/ INSTALLATI ON [MZR 2.5] .)
7	Oil pump component (See OIL PUMP REMOVAL/ INSTALLATI ON [MZR 2.5] .)