


2012 - Mazda6 - Engine

COOLING SYSTEM LOCATION INDEX [MZR 2.5]




1	Thermostat (See THERMOSTAT REMOVAL/ INSTALLATION [MZR 2.5].) (See THERMOSTAT INSPECTION [MZR 2.5].)
2	Cooling system cap (See COOLING SYSTEM CAP INSPECTION [MZR 2.5].)
3	Coolant reserve tank (See ENGINE COOLANT LEVEL INSPECTION [MZR 2.5].) (See COOLANT RESERVE TANK REMOVAL/ INSTALLATION [MZR 2.5].)
4	Cooling fan motor No.2 (See COOLING FAN MOTOR REMOVAL/ INSTALLATION [MZR 2.5].) (See COOLING FAN MOTOR INSPECTION [MZR 2.5].)
5	Fan control module (See FAN CONTROL MODULE INSPECTION [MZR 2.5].)
6	Cooling fan motor No.1 (See COOLING FAN MOTOR REMOVAL/ INSTALLATION [MZR 2.5].) (See COOLING FAN MOTOR INSPECTION [MZR 2.5].)

7	Radiator (See ENGINE COOLANT PROTECTION INSPECTION [MZR 2.5] .) (See ENGINE COOLANT REPLACEMENT [MZR 2.5] .) (See ENGINE COOLANT LEAKAGE INSPECTION [MZR 2.5] .) (See RADIATOR REMOVAL/ INSTALLATION [MZR 2.5] .)
8	Water pump (See WATER PUMP REMOVAL/ INSTALLATION [MZR 2.5] .)

2012 - Mazda6 - Engine

COOLING SYSTEM LOCATION INDEX [MZR 2.5]



1	Thermostat (See THERMOSTAT REMOVAL/ INSTALLATION [MZR 2.5].) (See THERMOSTAT INSPECTION [MZR 2.5].)
2	Cooling system cap (See COOLING SYSTEM CAP INSPECTION [MZR 2.5].)
3	Coolant reserve tank (See ENGINE COOLANT LEVEL INSPECTION [MZR 2.5].) (See COOLANT RESERVE TANK REMOVAL/ INSTALLATION [MZR 2.5].)
4	Cooling fan motor No.2 (See COOLING FAN MOTOR REMOVAL/ INSTALLATION [MZR 2.5].) (See COOLING FAN MOTOR INSPECTION [MZR 2.5].)
5	Fan control module (See FAN CONTROL MODULE INSPECTION [MZR 2.5].)
6	Cooling fan motor No.1 (See COOLING FAN MOTOR REMOVAL/ INSTALLATION [MZR 2.5].) (See COOLING FAN MOTOR INSPECTION [MZR 2.5].)

7	Radiator (See ENGINE COOLANT PROTECTION INSPECTION [MZR 2.5] .) (See ENGINE COOLANT REPLACEMENT [MZR 2.5] .) (See ENGINE COOLANT LEAKAGE INSPECTION [MZR 2.5] .) (See RADIATOR REMOVAL/ INSTALLATION [MZR 2.5] .)
8	Water pump (See WATER PUMP REMOVAL/ INSTALLATION [MZR 2.5] .)