


2012 - Mazda6 - Engine

COOLANT RESERVE TANK REMOVAL/ INSTALLATION [MZR 2.5]


- 1. Remove in the order indicated in the table.
- 2. Install in the reverse order of removal.



1	Wiring harness
2	Hose
3	Coolant reserve tank
	(See Coolant Reserve Tank Removal Note.)

Coolant Reserve Tank Removal Note

- 1. Remove the coolant reserve tank from the radiator cowl tabs shown in the figure by lifting them with a flathead screwdriver.



[< Previous](#) [Next >](#)


[Back to Top](#)

© 2011 Mazda North American Operations, U.S.A.

2012 - Mazda6 - Engine

COOLANT RESERVE TANK REMOVAL/ INSTALLATION [MZR 2.5]


- 1. Remove in the order indicated in the table.
- 2. Install in the reverse order of removal.



1	Wiring harness
2	Hose
3	Coolant reserve tank
	(See Coolant Reserve Tank Removal Note.)

Coolant Reserve Tank Removal Note

- 1. Remove the coolant reserve tank from the radiator cowl tabs shown in the figure by lifting them with a flathead screwdriver.



[< Previous](#) [Next >](#)

[Back to Top](#)

© 2011 Mazda North American Operations, U.S.A.