


2012 - Mazda6 - Engine

COOLING SYSTEM LOCATION INDEX [MZI 3.7 V6]



1Thermostat

(See [THERMOSTAT REMOVAL/ INSTALLATION \[MZI 3.7 V6\]](#).)


(See [THERMOSTAT INSPECTION \[MZI 3.7 V6\]](#).)

2Cooling system cap

	(See COOLING SYSTEM CAP INSPECTION [MZI 3.7 V6] .)
3	Coolant reserve tank (See ENGINE COOLANT LEVEL INSPECTION [MZI 3.7 V6] .) (See COOLANT RESERVE TANK REMOVAL/ INSTALLATION [MZI 3.7 V6] .)
4	Cooling fan motor No.2 (See COOLING FAN MOTOR REMOVAL/ INSTALLATION [MZI 3.7 V6] .) (See COOLING FAN MOTOR INSPECTION [MZI 3.7 V6] .)
5	Fan control module (See FAN CONTROL MODULE INSPECTION [MZI 3.7 V6] .)
6	Cooling fan motor No.1 (See COOLING FAN MOTOR REMOVAL/ INSTALLATION [MZI 3.7 V6] .) (See COOLING FAN MOTOR INSPECTION [MZI 3.7 V6] .)
7	Radiator (See ENGINE COOLANT PROTECTION INSPECTION [MZI 3.7 V6] .) (See ENGINE COOLANT REPLACEMENT [MZI 3.7 V6] .) (See ENGINE COOLANT LEAKAGE INSPECTION [MZI 3.7 V6] .) (See RADIATOR REMOVAL/ INSTALLATION [MZI 3.7 V6] .)
8	Water pump (See WATER PUMP REMOVAL/ INSTALLATION [MZI 3.7 V6] .)

2012 - Mazda6 - Engine

COOLING SYSTEM LOCATION INDEX [MZI 3.7 V6]



1Thermostat

(See [THERMOSTAT REMOVAL/ INSTALLATION \[MZI 3.7 V6\].](#))

(See [THERMOSTAT INSPECTION \[MZI 3.7 V6\].](#))

2Cooling system cap

	(See COOLING SYSTEM CAP INSPECTION [MZI 3.7 V6] .)
3	Coolant reserve tank (See ENGINE COOLANT LEVEL INSPECTION [MZI 3.7 V6] .) (See COOLANT RESERVE TANK REMOVAL/ INSTALLATION [MZI 3.7 V6] .)
4	Cooling fan motor No.2 (See COOLING FAN MOTOR REMOVAL/ INSTALLATION [MZI 3.7 V6] .) (See COOLING FAN MOTOR INSPECTION [MZI 3.7 V6] .)
5	Fan control module (See FAN CONTROL MODULE INSPECTION [MZI 3.7 V6] .)
6	Cooling fan motor No.1 (See COOLING FAN MOTOR REMOVAL/ INSTALLATION [MZI 3.7 V6] .) (See COOLING FAN MOTOR INSPECTION [MZI 3.7 V6] .)
7	Radiator (See ENGINE COOLANT PROTECTION INSPECTION [MZI 3.7 V6] .) (See ENGINE COOLANT REPLACEMENT [MZI 3.7 V6] .) (See ENGINE COOLANT LEAKAGE INSPECTION [MZI 3.7 V6] .) (See RADIATOR REMOVAL/ INSTALLATION [MZI 3.7 V6] .)
8	Water pump (See WATER PUMP REMOVAL/ INSTALLATION [MZI 3.7 V6] .)