

[< Previous](#) [Next >](#)

2012 - Mazda6 - Engine

EXHAUST SYSTEM INSPECTION [MZR 2.5]

1. Start the engine and inspect each exhaust system component for exhaust gas leakage.
 - If there is leakage, repair or replace the appropriate component. (See [EXHAUST SYSTEM REMOVAL/ INSTALLATION \[MZR 2.5\]](#).)

[< Previous](#) [Next >](#)

[Back to Top](#)

© 2011 Mazda North American Operations, U.S.A.

[< Previous](#) [Next >](#)

2012 - Mazda6 - Engine

EXHAUST SYSTEM INSPECTION [MZR 2.5]

1. Start the engine and inspect each exhaust system component for exhaust gas leakage.
 - If there is leakage, repair or replace the appropriate component. (See [EXHAUST SYSTEM REMOVAL/ INSTALLATION \[MZR 2.5\]](#).)

[< Previous](#) [Next >](#)

[Back to Top](#)

© 2011 Mazda North American Operations, U.S.A.