


2012 - Mazda6 - Engine

POSITIVE CRANKCASE VENTILATION (PCV) FITTING REMOVAL/ INSTALLATION [MZI 3.7 V6]

1. Disconnect the negative battery cable. (See [BATTERY REMOVAL/ INSTALLATION \[MZI 3.7 V6\]](#) .)
2. Set the power steering fluid tank out of the way. (See [POWER STEERING OIL PUMP REMOVAL/ INSTALLATION \[MZI 3.7 V6\]](#) .)
3. Remove in the order indicated in the table.



1	PCV valve hose
2	PCV fitting
3	O-ring

4. Install in the reverse order of removal.

[< Previous](#) [Next >](#)


[Back to Top](#)

© 2011 Mazda North American Operations, U.S.A.

2012 - Mazda6 - Engine

POSITIVE CRANKCASE VENTILATION (PCV) FITTING REMOVAL/ INSTALLATION [MZI 3.7 V6]

1. Disconnect the negative battery cable. (See [BATTERY REMOVAL/ INSTALLATION \[MZI 3.7 V6\]](#) .)
2. Set the power steering fluid tank out of the way. (See [POWER STEERING OIL PUMP REMOVAL/ INSTALLATION \[MZI 3.7 V6\]](#) .)
3. Remove in the order indicated in the table.



1	PCV valve hose
2	PCV fitting
3	O-ring

4. Install in the reverse order of removal.

[< Previous](#) [Next >](#)

[Back to Top](#)

© 2011 Mazda North American Operations, U.S.A.