



2012 - Mazda6 - Engine

EVAPORATIVE CHAMBER INSPECTION [MZI 3.7 V6]


1. Remove the evaporative chamber. (See [EVAPORATIVE CHAMBER REMOVAL/ INSTALLATION \[MZI 3.7 V6\]](#).)
2. Plug the port C.



3. Verify that there is air flow from port B when pressure is applied to port A.
 - If there is no airflow, replace the evaporative chamber. (See [EVAPORATIVE CHAMBER REMOVAL/ INSTALLATION \[MZI 3.7 V6\]](#).)
4. Remove the plug of port C.
5. Plug the port B.



6. Verify that there is air flow from port C when pressure is applied to port A.
 - If there is no airflow, replace the evaporative chamber. (See [EVAPORATIVE CHAMBER REMOVAL/ INSTALLATION \[MZI 3.7 V6\]](#).)
7. Remove the plug of port B.
8. Verify that there is air flow when vacuum is applied to port A.



- If there is no airflow, replace the evaporative chamber. (See [EVAPORATIVE CHAMBER REMOVAL/ INSTALLATION \[MZI 3.7 V6\]](#).)

[< Previous](#) [Next >](#)


[Back to Top](#)

© 2011 Mazda North American Operations, U.S.A.


2012 - Mazda6 - Engine

EVAPORATIVE CHAMBER INSPECTION [MZI 3.7 V6]


1. Remove the evaporative chamber. (See [EVAPORATIVE CHAMBER REMOVAL/ INSTALLATION \[MZI 3.7 V6\]](#).)
2. Plug the port C.



3. Verify that there is air flow from port B when pressure is applied to port A.
 - If there is no airflow, replace the evaporative chamber. (See [EVAPORATIVE CHAMBER REMOVAL/ INSTALLATION \[MZI 3.7 V6\]](#).)
4. Remove the plug of port C.
5. Plug the port B.



6. Verify that there is air flow from port C when pressure is applied to port A.
 - If there is no airflow, replace the evaporative chamber. (See [EVAPORATIVE CHAMBER REMOVAL/ INSTALLATION \[MZI 3.7 V6\]](#).)
7. Remove the plug of port B.
8. Verify that there is air flow when vacuum is applied to port A.



- If there is no airflow, replace the evaporative chamber. (See [EVAPORATIVE CHAMBER REMOVAL/ INSTALLATION \[MZI 3.7 V6\]](#).)

[< Previous](#) [Next >](#)

[Back to Top](#)

© 2011 Mazda North American Operations, U.S.A.