


2012 - Mazda6 - Engine


IGNITION SYSTEM LOCATION INDEX [MZR 2.5]



1	Ignition coil (See IGNITION COIL REMOVAL/ INSTALLATION [MZR 2.5].) (See IGNITION COIL INSPECTION [MZR 2.5].)
2	Spark plug (See SPARK PLUG REMOVAL/ INSTALLATION [MZR 2.5].) (See SPARK PLUG INSPECTION [MZR 2.5].)

2012 - Mazda6 - Engine

IGNITION SYSTEM LOCATION INDEX [MZR 2.5]



1	Ignition coil (See IGNITION COIL REMOVAL/ INSTALLATION [MZR 2.5].) (See IGNITION COIL INSPECTION [MZR 2.5].)
2	Spark plug (See SPARK PLUG REMOVAL/ INSTALLATION [MZR 2.5].) (See SPARK PLUG INSPECTION [MZR 2.5].)