



[< Previous](#) [Next >](#)

2012 - Mazda6 - Engine

IGNITION SYSTEM LOCATION INDEX [MZI 3.7 V6]



1 Ignition coil

(See [IGNITION COIL REMOVAL/ INSTALLATION \[MZI 3.7 V6\]](#) .)

(See [IGNITION COIL INSPECTION \[MZI 3.7 V6\]](#) .)

2 Spark plug



(See [SPARK PLUG REMOVAL/ INSTALLATION \[MZI 3.7 V6\]](#) .)

(See [SPARK PLUG INSPECTION \[MZI 3.7 V6\]](#) .)

[< Previous](#) [Next >](#)

2012 - Mazda6 - Engine

IGNITION SYSTEM LOCATION INDEX [MZI 3.7 V6]



1 Ignition coil

(See [IGNITION COIL REMOVAL/ INSTALLATION \[MZI 3.7 V6\]](#) .)

(See [IGNITION COIL INSPECTION \[MZI 3.7 V6\]](#) .)

2 Spark plug

(See [SPARK PLUG REMOVAL/ INSTALLATION \[MZI 3.7 V6\]](#) .)

(See [SPARK PLUG INSPECTION \[MZI 3.7 V6\]](#) .)

