


2012 - Mazda6 - Engine

STARTING SYSTEM LOCATION INDEX [MZR 2.5]



1 Starter interlock switch (MTX)

(See [STARTER INTERLOCK SWITCH INSPECTION \[MZR 2.5\]](#).)

2 Starter


(See [STARTER REMOVAL/ INSTALLATION \[MZR 2.5\]](#).)

(See [STARTER INSPECTION \[MZR 2.5\]](#).)

(See [STARTER DI SASSEMBLY/ ASSEMBLY \[MZR 2.5\]](#).)

2012 - Mazda6 - Engine

STARTING SYSTEM LOCATION INDEX [MZR 2.5]



1 Starter interlock switch (MTX)

(See [STARTER INTERLOCK SWITCH INSPECTION \[MZR 2.5\]](#).)

2 Starter

(See [STARTER REMOVAL/ INSTALLATION \[MZR 2.5\]](#).)

(See [STARTER INSPECTION \[MZR 2.5\]](#).)

(See [STARTER DI SASSEMBLY/ ASSEMBLY \[MZR 2.5\]](#).)