

[< Previous](#) [Next >](#)

2012 - Mazda6 - Engine

BAROMETRIC PRESSURE (BARO) SENSOR REMOVAL/ INSTALLATION [MZR 2.5]

NOTE:

- The BARO sensor cannot be removed as a single unit. When replacing the BARO sensor, replace it together with the PCM as a single unit.
1. Remove the PCM. (See [PCM REMOVAL/ INSTALLATION \[MZR 2.5\]](#).)

[< Previous](#) [Next >](#)

[Back to Top](#)

© 2011 Mazda North American Operations, U.S.A.

[< Previous](#) [Next >](#)

2012 - Mazda6 - Engine

BAROMETRIC PRESSURE (BARO) SENSOR REMOVAL/ INSTALLATION [MZR 2.5]

NOTE:

- The BARO sensor cannot be removed as a single unit. When replacing the BARO sensor, replace it together with the PCM as a single unit.
1. Remove the PCM. (See [PCM REMOVAL/ INSTALLATION \[MZR 2.5\]](#).)

[< Previous](#) [Next >](#)

[Back to Top](#)

© 2011 Mazda North American Operations, U.S.A.