


2012 - Mazda6 - DriveLine/ Axle

DRIVE SHAFT LOCATION INDEX



1 Drive shaft

(See [DRIVE SHAFT INSPECTION](#).)

(See [DRIVE SHAFT REMOVAL/ INSTALLATION](#).)

(See [DRIVE SHAFT \(TRI POD JOINT\) DI SASSEMBLY/ ASSEMBLY](#).)

(See [DRIVE SHAFT \(DOUBLE OFFSET JOINT\) DI SASSEMBLY/ ASSEMBLY](#).)

2 Joint shaft

(See [JOINT SHAFT INSPECTION](#).)

(See [JOINT SHAFT REMOVAL/ INSTALLATION](#).)

(See [JOINT SHAFT DI SASSEMBLY \[MZR 2.5 \]](#).)

(See [JOINT SHAFT DI SASSEMBLY \[MZI 3.7 V6 \]](#).)

(See [JOINT SHAFT ASSEMBLY \[MZR 2.5 \]](#).)

(See [JOINT SHAFT ASSEMBLY \[MZI 3.7 V6 \]](#).)


[< Previous](#) [Next >](#)

[Back to Top](#)

© 2011 Mazda North American Operations, U.S.A.

2012 - Mazda6 - DriveLine/ Axle

DRIVE SHAFT LOCATION INDEX



1	Drive shaft (See DRIVE SHAFT INSPECTION .) (See DRIVE SHAFT REMOVAL/ INSTALLATION .) (See DRIVE SHAFT (TRI POD JOINT) DI SASSEMBLY/ ASSEMBLY .) (See DRIVE SHAFT (DOUBLE OFFSET JOINT) DI SASSEMBLY/ ASSEMBLY .)
2	Joint shaft (See JOINT SHAFT INSPECTION .)

(See [JOINT SHAFT REMOVAL/ INSTALLATION](#).)

(See [JOINT SHAFT DI SASSEMBLY \[MZR 2.5 \]](#).)

(See [JOINT SHAFT DI SASSEMBLY \[MZI 3.7 V6 \]](#).)

(See [JOINT SHAFT ASSEMBLY \[MZR 2.5 \]](#).)

(See [JOINT SHAFT ASSEMBLY \[MZI 3.7 V6 \]](#).)

[< Previous](#) [Next >](#)

[Back to Top](#)

© 2011 Mazda North American Operations, U.S.A.