


2012 - Mazda6 - DriveLine/ Axle

DRIVE SHAFT INSPECTION

1. Inspect the connections for any looseness.




- If there is any malfunction, tighten or replace the applicable part.
2. Inspect the dust boot for damage and cracks.
 - If there is any malfunction, replace the applicable part.
 3. Move the spline and joint up and down, left and right by hand and verify that there is no excessive play.
 - If there is any malfunction, replace the applicable part.

2012 - Mazda6 - DriveLine/ Axle

DRIVE SHAFT INSPECTION

1. Inspect the connections for any looseness.



- If there is any malfunction, tighten or replace the applicable part.
2. Inspect the dust boot for damage and cracks.
 - If there is any malfunction, replace the applicable part.
 3. Move the spline and joint up and down, left and right by hand and verify that there is no excessive play.
 - If there is any malfunction, replace the applicable part.