


2012 - Mazda6 - Brakes

PARKING BRAKE LEVER ADJUSTMENT

NOTE:

- After pumping the brake pedal a few times, adjust the parking brake lever.
1. Remove the upper panel. (See [UPPER PANEL REMOVAL/ INSTALLATION.](#))
 2. Turn the adjusting nut as shown in the figure to adjust.




3. After adjustment, confirm the following points:
 - If there is any malfunction, inspect the parking brake lever again.
 - a. Pull the parking brake lever one notch and verify that the parking brake warning light illuminates.
 - b. Release the parking brake lever completely, and verify that the rear brakes do not drag.

2012 - Mazda6 - Brakes

PARKING BRAKE LEVER ADJUSTMENT

NOTE:

- After pumping the brake pedal a few times, adjust the parking brake lever.
1. Remove the upper panel. (See [UPPER PANEL REMOVAL/ INSTALLATION.](#))
 2. Turn the adjusting nut as shown in the figure to adjust.



3. After adjustment, confirm the following points:
 - If there is any malfunction, inspect the parking brake lever again.
 - a. Pull the parking brake lever one notch and verify that the parking brake warning light illuminates.
 - b. Release the parking brake lever completely, and verify that the rear brakes do not drag.